

## Application examples from practice

	Diatomaceous earth [g/hl]	Protein stabilisation [g/hl]
Diatomaceous earth & Xerogel	134	98
Diatomaceous earth & Celite Cynergy® 200HS	39	96
Reduction diatomaceous earth dosage	- 71 %	
Diatomaceous earth & Xerogel	159	76
Diatomaceous earth & Celite Cynergy® 200HS	88	71
Reduction diatomaceous earth dosage	- 45 %	
Diatomaceous earth & Xerogel	69	18
Diatomaceous earth & Celite Cynergy® 200HS	48	17
Reduction diatomaceous earth dosage	- 30 %	
Diatomaceous earth & Xerogel	123	37
Diatomaceous earth & Celite Cynergy® 200HS	82	39
Reduction diatomaceous earth dosage	- 33 %	