

Presentation

Cleaning in place (CIP)


Lehmann&Voss&Co. KG

Alsterufer 19

20354 Hamburg

Established Technology for future challenges






- Fitration in Cross-Flow mode. Permeate is discarged via the permeate tank.




2 - Permeat Backwash



- Permeate is pumped from the permeate tank via back wash pump through the membrane in reverse direction.




(rinsing after cleaning)



- Fitration in Cross-Flow mode. Permeat is discarged via the permeate tank.




4 - Chemical Enchanced Backwash (CEB)



- Permeate is pumped from the permeate tank via back wash pump through the membrane in reverse direction.
- Cleaning chemicals are dosed in the permeate water stream (yellow)




(rinsing after cleaning)



- Fitration in Cross-Flow mode. Permeate is discarged via the permeate tank.




6 - Cleaning in place (CIP) - Tank Filling



- Fitration in Cross-Flow mode. Permeate is led to the cleaning tank.




7 - Cleaning in place (CIP) - Cleaner Dosing



- Chemicals are dosed in the cleaning tank. Dosing is controlled either by cleaner concentration or pH value.




8 - Cleaning in place (CIP) - Intermittend Cross Flow Cleaning



- Cleaning solution is pumped (intermittend) through the module without pressure and both streams are led back to the cleaning tank.
- Although there is no operating pressure applies, small amount of cleaner/water will pass the membrane.




9 - Cleaning in place (CIP) - Cleaner Discharge ((rinsing after cleaning)



- Fitration in Cross-Flow mode. Permeate is discarged to waste water until all chenical are flushed out of the system.



(rinsing after cleaning)



- Fitration in Cross-Flow mode. Permeate is discarged via the permeate tank.



Cleaning Agents

Organic fouling - caustic (NaOH); sodium hypochloride (NaClO)

Inorganic fouling - acidic (HCl, H₂SO₄)

Proteins, Biomass - enzymatic

Iron fouling - complexing agents (citric acid)

Note

Acid (<pH 7) - closes membrane

Caustic (>pH 7) - openes the membrane (last rinsing with caustic and water)



Lehmann&Voss&Co. KG

The consequence of experience of

a successful business model.

Established Technology for future challenges